



Ruffwear

Sizing Chart & Technical Specs Float Coat

Use the sizing chart to find the right size for your dog. In between sizes: Choose the smaller size.

Size	Girth
XXS	13-17 in (33-43 cm)
XS	17-22 in (43-56 cm)
S	22-27 in (56-69 cm)
M	27-32 in (69-81 cm)
L	32-36 in (81-91 cm)
XL	36-42 in (91- 107 cm)





Size	Length (A)	Neck (B)
XXS	7.25 in (18.5 cm)	10.5-12.75 in (27-32.5 cm)
XS	10.25 in (26 cm)	12.25-16.25 in (31-41 cm)
S	11.75 in (30 cm)	15-19.75 in (38-50 cm)
M	15 in (38 cm)	17.75-23.25 in (45-59 cm)
L	16.25 in (41.5 cm)	20.75-26.75 in (53-68 cm)
XL	19.25 in (49 cm)	22.75-29.5 in (58-75 cm)

Coverage Style

